

Acrylic Desktop Screens



Scan our QR code to
view the full
assembly video

Step 1

Take the supplied clamp and tighten from underneath, until the clamp is securely positioned.

Step 2

Take your acrylic desktop screen and place in the top clamp located on the top section of the desk.

Step 3

Once the acrylic is in position with the clamp, tighten the fixing with the supplied allen key. This will lock the acrylic screen in place.

