

## Universal Display Boards



Scan our QR code to  
view the full  
assembly video



### Step 1

Place the round base on the floor and screw the pole into the base using the thread at the end of the pole.



### Step 2

Slide a Universal corner moulding down 1 of the 4 channels on the pole.



### Step 3

Secure the moulding in place with a screwdriver. Set at the correct height for your display boards. Repeat this process on any remaining poles.



### Step 4

Lift the display panel on top of the corner fittings. The corner fittings fit into the frame of the display board.



## Step 5

Slide 1 corner moulding down each pole, this will slot into the top corners of the first display board. Twist the pole for easy access to the screw within the corner fixing & secure with a screwdriver.



## Step 6

If you're stacking 2 display boards, slide 2 more corner mouldings down the poles, lock into place and add the board on top of the corners.



## Step 7

Insert the top corner fixing, twist the pole for access to the screw and secure.



## Step 8 (Optional)

To add the header panel, insert the header pole into the top of the main pole. Secure corner mouldings.



## Step 9 (Optional)

Add the header panel on top of the corner fixings, finish installation by adding the top corner mouldings and fastening.