Pop Up Display Stand



Scan our QR code to view the full assembly video



Pop Up Frame Magnetic Bars Printed Graphic Panels Portable Storage case



Step 1Open the Pop Up frame gently, keeping the red clips at the top of the frame.



Step 2Place the magnetic bars into the designated positions to lock the frame together.



Step 3
Unroll each of the graphic panels, and connect the top hook on the back of the panel with the hook at the top of the Pop Up Stand frame.

go displays




Step 4

Start with panel 1 and work your way across the stand, hooking all panels to the top of stand and lining up as you go along. Ensure the graphics line up with the magnetic bars.



Step 5 (Optional)

To fit the spotlight, insert the base of the light in-between the top section of tubular frame next to the cross sections & pull downwards letting the spotlight rest on the frame.





Please make sure you lift the magnetic bars apart and do not rub the backing magnet across the face of the bar. This will result in the magnetism being lost in the bar which will not be covered under the guarantee.







Step 1
Locate the first graphic panel as indicated by the yellow slip



Step 2
Coil the graphic panel inwards, with both hands.

Remove the panel as shown in the illustration



Step 3

Lift the graphic panel out slowly making sure you do not catch the panel on the remaining graphic panels.

Then follow the assembly instructions on attaching the graphic panels



Step 4

The remaining graphic panels are shown in the storage case.


Follow steps 1 to 3 until all the graphic panels have been assembled

Pop Up Display Care Sheet

Storing your graphics







- Store your graphics in the case provided, do not roll them too tight as this can permanently curl the panels.
- Place into the case one at a time/remove one at a time
- We recommend storing the panels at room temperature for 24 hours before use to avoid the panels curling.

Panels not lining up correctly?





Correct

Incorrect


- Check the panels are attached on the twin pegs (top of the frame) correctly
- We do have an industry standard and allow for a 2.5mm tolerance per panel, 5mm over two panels. However we try to better this tolerance

• Detach the graphic at the bottom on both sides by 300m and move for finer adjustments

Magnets not working?



• Make sure the magnetic vertical bars are fitted to the frame



• Check the graphic panels are lined up with the centre line of the magnetic bar, if this overlaps by just a little it will give the appearance that part of the magnetic bar will not work

Marks on your graphics?







• Use a cloth dampened with tepid water (no chemicals) and gently rub over the mark. This should resolve your issue